

01. Remove pop up frame, counter top and supporting struts from the box, and the counter graphic wrap from the tube.

02. You should have:

- | | |
|-------------------------|---|
| 1 x Pop Up Frame | 4 x Magnetic Curved End Supports |
| 1 x Counter Top | 4 x Magnetic Straight Horizontal Supports |
| 3 x Shelves | 6 x Straight Horizontal Supports |
| 4 x Curved End Supports | 6 x Magnetic Straight Vertical Supports |
| | 6 x Straight Vertical Supports |

03. Erect pop up frame ensuring the locating studs for the counter top are at the top of the frame

04. Fix the curved end supports to the end of the counter. The magnetic supports should be at the top and bottom of the counter with the standard supports in the middle.

05. Fix the horizontal supports to the front of the counter. Again, the magnetic supports should be at the top and bottom of the counter with the standard supports in the middle. Once you have done this you can fix the smaller curved supports to the remaining positions at the back of the frame.

06. Fix the magnetic straight supports vertically at the back of the counter so that the magnets link to the magnetic curved end supports.

07. Fix the remaining 6 straight supports vertically to the front of the unit.

08. Place the counter top on to the top of the pop up frame, ensuring that the holes in the counter align with the locating studs on the frame.

09. Unroll the graphic wrap and place the magnetic strips on the wrap so they align with the vertical magnetic strips at the back of the pop up frame.

10. Wrap the graphic around the front of the counter frame ensuring that the magnetic strips align at the top and bottom of the frame until the second set of vertical strips align and can be joined together.

11. Place the three shelves in to the back of the counter. Slightly angle the shelves to help them locate.

12. The counter is now complete. To dismantle, please reverse the assembly procedure.

