

01. Lay out the tarpaulin and unroll your dome into a V shape, as shown in the photo.
02. At the bottom of all four legs, screw the bung into the valve (finger tight) and leave the outer valve cap off.
03. Using the rechargable pump, hold the nozzle onto the inflation valve of one of the top legs.
04. Inflate the top two legs until no further pressure is being created. They will reach a maximum of 80%.
05. Using the hand pump, inflate the top two legs to full inflation. 12-14 repetitions should ensure maximum air pressure & rigidity.
06. Using the rechargable pump, inflate the lower legs until no further pressure is being created, ensuring they are between the top two legs.
07. From the rear, lift the spider dome and pull the two lower legs through to stand the dome up.
08. Using the hand pump, inflate the lower (rear) legs to full inflation. 12-14 repetitions should ensure maximum air pressure & rigidity.
09. Ensure all legs are fully pressurised and close every outer valve cap.
10. Anchor the dome using weight plates (additional extra) and ground stakes.
11. To zip on the side walls, zip up from the bottom of each side. Both zippers should meet in the middle at the highest point of the wall. Attach as many walls as required.
12. Remove the tarpaulin from under the dome and setup is complete.

